

Add extra power to your alignment system

Easy-Laser PLUS™は、次の目的に適したクラウドソリューションです。

- ✓ メンテナンスチームと協力して仕事の割り当て
- ✓ チームの測定ファイルを1か所に収集、概要説明と分析を迅速に
- ✓ タブレットを紛失または破損した場合は、測定データを新しいデバイスにコピー
- ✓ タブレット上で誤って削除したファイルを復元
- ✓ 最新ソフトウェアアップデートに関する情報を受け取り

Easy-Laser PLUS™は、チームの測定作業のハブであり、データのセキュリティを強化します。しかし、それだけではありません。

今すぐ無料でeasylaser.plus をお試しください。





Power up with Easy-Laser PLUS™

次の目的に適したラウドソリューションです。

- 目的に適したラウドソリューションです。
- メンテナンスチームと協力して仕事の割り当て
- チームの測定ファイルを1か所に収集、概要説明と 分析を迅速に
- タブレットを紛失または破損した場合は、測定データを新しいデバイスにコピー
- タブレット上で誤って削除したファイルを復元
- 最新のソフトウェアアップデートに関する情報を受け取り

これは始まりにすぎません。Easy-Laser PLUS™は測定器 を補完し、さらに強力にする可能性を提供していきま す。

Easy-Laser XT システム用

Easy-Laser PLUS™ は、サードパーティーのタブレットやスマートフォン、および当社のXT12またはXT11 rev2 で動作します。

アカウントでデバイスをペアリングする時、Wi-Fiが利用可能になる度にシステムで即座に利用できるようになります。Easy-Laser PLUS™には、ウェブブラウザからアク

セスします。

How does it work?

In Easy-Laser PLUS™ you organize your data in "workspaces", in a way that makes most sense for you and your team. For example a Project, Team, Customer or Machinery workspace. Once you have created your workspace, you can start inviting team members.


You can set different user roles (e.g. Administrator, Contributor or Viewer). This means you can set a temporary Viewer right to a service provider or a client when working on a project together.

Data protection


All data are securely transferred with SSL/TLS encryption. The data is only accessible for those who have the right user level. At introduction the secure servers are located in the EU. Easy-Laser can by default only view anonymous data, but you can give temporary access, for example for support issues.

Get it now!

サブスクリプションを開始するには、easylaser.plus にアクセスし、簡単な手順でアクントを登録してください。新しいアカウントを作成すると、30日間の無料トライアル期間が提供されます。ユーザー契約とデータ保護の詳細については、easylaser.comをご覧ください。



You organize your data in "workspaces", in a way that makes most sense for you and your team. For example projects, team, customer or machine type. (Note: graphics enlarged for clarity.)



Above is an example of setups/workflows with Easy-Laser PLUS™.

- The organization (your company account) controls user access.
- You set different user roles (Administrator, Contributor or Viewer).
- Users can access one or more accounts.
- You pair your devices (or XT apps, that is), making them instantly available in Easy-Laser PLUS™.
- Each XT app can be paired with one account.